1	Before driving	1-5.	Refueling Opening the fuel tank cap 97
1-1.	Key information	1-6.	Theft deterrent system
	Keys 26		Engine immobilizer system 101 Alarm 103
1-2.	Opening, closing and locking the doors		Theft prevention labels (for U.S.A.)106
	Smart access system with push-button start	1-7.	Safety information
	Wireless remote control		Correct driving posture 107
	Side doors 47		SRS airbags 109
	Back door 50		Front passenger occupant classification system
1-3.	Adjustable components		Child restraint systems 127
	(seats, mirrors,		Installing child restraints131
	steering wheel)		
	Front seats	2	When driving
	Driving position memory		
	Head restraints	2-1.	Driving procedures
	Seat belts		Driving the vehicle 144
	Steering wheel83		Engine (ignition) switch 153
	Anti-glare inside rear view		Automatic transmission
	mirror 85		Turn signal lever 163
	Outside rear view mirrors 87		Parking brake 164
			Horn 165
1-4.	Opening and closing the		
	windows and moon roof		
	Power windows 90		
	Moon roof93		

	Gauges and meters 166		Utility vehicle precautions	244
	Indicators and warning		Cargo and luggage	249
	lights 168		Vehicle load limits	253
	Multi-information display 173		Winter driving tips	254
	Head-up display 179		Trailer towing	258
			Dinghy towing	270
2-3.	Operating the lights and windshield wipers			
	Headlight switch	3	Interior features	
	Automatic High Beam 189			
	Fog light switch	3-1.	Using the air conditioning	
	Windshield wipers and		system and defogger	
	washer 197		Automatic air conditioning	
	Rear window wiper and		system	274
	washer202		Rear window defogger	
	Headlight cleaner switch 203		switch	281
0.4	The all the control of		Windshield wiper de-icer	282
2-4.	Using other driving systems			
	Cruise control 204	3-2.	Using the audio system	
	Dynamic radar cruise		Audio system	283
	control		Using the radio	287
	Intuitive parking assist		Using the CD player	297
	Rear view monitor system (rear view mirror-attached type)		Playing MP3 and	
			WMA discs	
	Driving assist systems		Operating an iPod	
	All-wheel drive lock switch		Operating a USB memory	325
	(AWD models)237		Optimal use of the	22.4
	Hill-start assist control		audio system	
	Pre-Collision System240		Using the AUX port	337
			Using the steering wheel audio switches	220
			audio switches	၁၁ຯ

2-2. Instrument cluster

Cargo and luggage	249
Vehicle load limits	253
Winter driving tips	254
Trailer towing	258
Dinghy towing	270

features

2-5. Driving information

system and defogger	
Automatic air conditioning	_

he audio system

Audio system	283
Using the radio	287
Using the CD player	297
Playing MP3 and WMA discs	307
Operating an iPod	317
Operating a USB memory	325
Optimal use of the audio system	334
Using the AUX port	
Using the steering wheel audio switches	339

3-3.	Using the Bluetooth $^{\circledR}$ audio	3-6.	Using the storage features
	system Bluetooth® audio system 342 Using the Bluetooth® audio system		List of storage features
	Bluetooth [®] audio system setup	3-7.	Other interior features
			Sun visors 408
3-4.	. Using the hands-free phone system (for mobile phones)		Vanity mirrors 409
			Clock410
			Outside temperature display 411
	Hands-free system for mobile phones		Multi-display light control (vehicles without a navigation system)
	Security and system setup 385		Floor mat
	Using the phone book 389		Luggage compartment features
3-5.	Using the interior lights Interior lights list		Garage door opener
			Compass
			Safety Connect

6

4-1.	Maintenance and care	5-1.	Essential information
	Cleaning and protecting the vehicle exterior 444		Emergency flashers 524 If your vehicle needs to
	Cleaning and protecting		be towed 525
	the vehicle interior447		If you think something is wrong
4-2.	Maintenance		Fuel pump shut off system 532
	Maintenance requirements 450 General maintenance		Event data recorder533
	Emission inspection and	5-2.	Steps to take in an emergency
	maintenance (I/M) programs456	J-Z.	If a warning light turns on or a warning buzzer sounds
4-3.	Do-it-yourself maintenance		If a warning message is
	Do-it-yourself service		displayed545
	precautions 457		If you have a flat tire564
	Hood460		If the engine will not start 577
	Positioning a floor jack		If the shift lever cannot be shifted from P
	Tires		If you lose your keys 580
	Tire inflation pressure487		If the electronic key does
	Wheels 491		not operate properly
	Air conditioning filter493		If the battery is discharged 584
	Electronic key battery 496		If your vehicle overheats 587
	Checking and replacing fuses		If the vehicle becomes stuck
	Headlight aim (discharge headlights) 509		If your vehicle has to be stopped in an emergency
	Light bulbs 511		

Maintenance and care

al information ency flashers 524 vehicle needs to ved...... 525 nink somethina ong...... 531 imp shut off system 532 ata recorder......533 o take in an emergency ning light turns a warning buzzer ls... 535 ning message is yed......545 ave a flat tire......564 ngine will not start 577 ift lever cannot be d from P...... 579 ose your keys...... 580 ectronic key does perate properly 581 attery is discharged 584 ehicle overheats......587 ehicle becomes 590 ehicle has to be ed in an

When trouble arises

for Canadian owners

6	Vehicle specifications	Index	
6-1.	Specifications	Abbreviation list	648
	Maintenance data (fuel, oil level, etc.)	Alphabetical index	650
	Tire information 609	What to do if	665
6-2.	Customization		
	Customizable features 621		
6-3.	Initialization		
0-3.	Items to initialize 630		
7	For owners		
	Reporting safety defects for U.S. owners		
	Seat belt instructions for Canadian owners (in French)		
	SRS airbag instructions		